RI.2 Technologies

# Datasheet

# CMX25S03

Rev. 1.1

Copyright © 2019 RN2 Technologies Co., Ltd. All Rights Reserved.

#### **Revision History**

Rev	Release Date	Description	Author
1.0	2019-07-25	<ul> <li>Initial release</li> </ul>	Y.J. Ko
1.1	2020-07-27	<ul> <li>Expand specification</li> </ul>	Y.J. Ko



#### Contents

KEY FEATURES	4
APPLICATIONS	4
GENERAL DESCRIPTIONS	4
ELECTRICAL SPECIFICATIONS	4
PORT CONFIGURATIONS	5
OUT DIMENSION	
POWER DERATING CURVE	6
RF Characteristics: Return Loss (at -55 °C, 25 °C, and 125°C)	7
RF Characteristics: Coupling, Transmission, Insertion Loss and Phase B	alance
(at -55 °C, 25 °C, and 125°C)	8
RF TEST METHODS	
10.1 RF TEST PROCEDURES	9
10.2 RN2 Technologies TEST BOARD LAYOUT	12
10.3 AUTOMATIC PORT EXTENSIONS (APE) FUNCTION	13
RECOMMENDED PCB LAND PATTERN	14
SOLDERING PROCESS	15
REFLOW PROFILE	16
PACKAGING AND ORDERING INFORMATION	17
HANDLING GUIDE	18
LEGAL INFORMATION	



# 3dB, Asymmetric Coupler with High-Power Capacity and Stable Performance based on RN2 LTCC Multilayer Technology

## **1. KEY FEATURES**

- Frequency range 1800 2690 MHz
- Excellent high-power capacity up to average 350 watts
- Excellent stable performance at different temperatures
- Low insertion loss Max 0.12 dB high conductivity metal
- conductor (Ag), and gold (Au) plating
- Small size (14.22 x 5.08 mm) SMD package
- RoHS compliance (Pb-Free)

#### 2. APPLICATIONS

- Applications using GSM, UMTS, and LTE
- RF amplifiers
- Communications equipment

# **3. GENERAL DESCRIPTIONS**

CMX25S03 is a 3dB, 90° hybrid coupler with high-power capacity and stable performance in different temperatures. The LTCC (Low Temperature Co-fired Ceramic), high conductivity metal conductor (Ag), and gold (Au) plating enable the CMX25S03 to minimize insertion loss and improve durability for thermal stabilization and electricity.

CMX25S03 is best application solution for GSM, UMTS, LTE and communications equipment, requiring low insertion loss and high power.


CMX25S03 supports up to CW average 350 W. It's package type is a SMD type product enabling Pb-Free solder and meets RoHS-6.

Frequency (MHz)	Amplitude Balance Max.(dB)	Isolation Min.(dB)	Insertion Loss Max.(dB)		
1800 – 2700	± 0.30	20	0.15		
2496 – 2690	± 0.25	23	0.12		
Return Loss Min.(dB)	Phase Balance (Degrees)	Power Capacity Avg.(Watt)	Operating Temperature(℃)		
00	00 + 1 0	050			
20	90 ±4.0	350	-55 - +125		

## 4. ELECTRICAL SPECIFICATIONS

**NOTE**: These electrical specifications are measured by using a RN2 Technologies test board. Specifications subject to change without notice.

For reliability test data, please contact RN2 Technologies sales team.



# **5. PORT CONFIGURATIONS**




Figure 1. Top View


CMX25S03 port configurations. The Case 1, Case 2, Case 3, and Case 4 configurations mean that one input signal is split into two output signals. When port 1 is defined, the other ports are defined automatically.

Table 1. CMX25S03 Port Configurations
---------------------------------------

Configuration	Port 1	Port 2	Port 3	Port 4
Case 1.	Input	Isolated	Output -90°	Coupling *0°
Case 2.	Isolated	Input	Coupling *0°	Output -90°
Case 3.	Output -90°	Coupling *0°	Input	Isolated
Case 4.	Coupling *0°	Output -90°	Isolated	Input

\*NOTE: 0° is an actual phase or amplitude of the frequency specified at all ports.

# 6. OUT DIMENSION



- Units: mm
- Weight: 0.38 grams

Camber specifications: Less than ±0.08 mm



## 7. POWER DERATING CURVE

The maximum allowable average power (Maximum input power, CW) of the CMX25S03 depending on base PCB temperature changes. The maximum allowable average power of the CMX25S03 is limited by the following power derating curve.

The CMX25S03 factors that determine the power derating curve are as follows:

- Internal circuit
- Thickness
- Thermal conductivity of materials
- Insertion loss
- Operating temperature
- Mounting interface temperature between the CMX25S03 and the base PCB

The maximum operating temperature of the CMX25S03 is 125 °C. Therefore, when the base PCB temperature is over 125 °C, the CMX25S03 operates stably by decreasing its durable average input power. When the base PCB temperature reaches 200 °C, the maximum allowable average power decreases to 0 watt.




Figure 2. Power Derating Curve

# 8. RF Characteristics: Return Loss (at -55 °C, 25 °C, and 125°C)





Figure 3. Test Plots of Return Loss (at -55 °C, 25 °C, and 125 °C)

RI.2 Technologies



# 9. RF Characteristics: Coupling, Transmission, Insertion Loss and Phase Balance (at -55 °C, 25 °C, and 125°C)

Figure 4. Test Plots of Coupling, Transmission Loss, Insertion Loss, Isolation and Phase Balance (at -55 °C, 25 °C, and 125 °C)

RI.2 Technologies

## **10. RF TEST METHODS**

To ensure S-Parameters reliability, we follow our internal test procedures by using the RN2 Technologies bare test board, RN2 Technologies test board, and test fixture connected with VNA (Vector Network Analyzer). In addition, we use the Automatic Port Extensions (APE) function of the Vector network analyzer to obtain accurate S-Parameters.

#### **10.1 RF TEST PROCEDURES**

To test the CMX25S03 RF performance, we perform the following steps:

- 1. Preparing the Test Equipment
- 2. Performing the APE Function of the VNA
- 3. Measuring the S-parameters (Coupling, Transmission Loss, Isolation, and Return Loss)
- 4. Obtaining the Characteristic Parameters (Amplitude Balance, Isolation, Insertion Loss, Return Loss, and Phase Balance)

#### **STEP 1: Preparing the Test Equipment**

The following test equipment is prepared to test the CMX25S03 RF performance.

- RN2 Technologies bare test board
- RN2 Technologies test board
- Vector network analyzer
- Test fixture

**NOTE**: See '<u>RN2 Technologies TEST BOARD LAYOUT</u>' for the RN2 Technologies test board details.

# STEP 2: Performing the Automatic Port Extensions (APE) Function of the Vector Network Analyzer

The APE function is used with the RN2 Technologies bare test board to correctly check the CMX25S03 RF performance. This reduces or eliminates both electrical delay and insertion loss of the test fixture.

The detailed steps are as follows:

- 1. Place the RN2 Technologies bare test board on the text fixture.
- 2. Click the **Cal** button of the VNA to calibrate it.
- 3. Connect the four ports of the test fixture into the fours ports of the VNA.
- 4. Click the **Port Extensions** button of the VNA to measure the data of the RN2 Technologies bare test board.

**NOTE**: See <u>'AUTOMATIC PORT EXTENSIONS FUNCTION'</u> for more details.



#### STEP 3: Measuring the S-parameters (Transmission Loss and Return Loss)

After performing the APE function, the CMX25S03 s-parameters are measured through the following steps:

- 1. Place the RN2 Technologies test board on the text fixture.
- 2. Apply pressure to the text fixture using a pneumatic piston.
- 3. Connect the three ports of the test fixture into the three ports of the Vector network analyzer.
- 4. Set port1 as Case 1 configuration in 'Table 1. CMX25S03 Port Configurations'.
- 5. Calibrate the Vector network analyzer.
- 6. Measure the coupling value from port 1 to port 4 (S41).
- 7. Measure the transmission loss value from port 1 to port 3 (S31).
- 8. Measure the isolation value from port 1 to port 2 (S21).
- 9. Measure the return loss value from port 1 to port 1, port 2 to port 2, port 3 to port 3, and port 4 to port 4 respectively (S11, S22, S33, and S44).




Figure 5. Test Setting to Measure the CMX25S03 S-parameters

# STEP 4: Obtaining the Characteristic Parameters (Insertion Loss, Return Loss, and Phase Balance)

The s-parameters are calculated by using the formula in *Table 2* to obtain the characteristic parameters, such as amplitude balance, isolation, insertion loss, return loss, and phase balance.

Parameter	S-Parameter	Power Method	
Coupling	S41	$10 \cdot \log\left(\frac{P_{cou}}{P_{in}}\right)$	
Transmission Loss	S31	$10 \cdot \log\left(\frac{P_{out}}{P_{in}}\right)$	
Isolation	S21	$10 \cdot \log\left(rac{P_{iso}}{P_{in}} ight)$	
Insertion Loss	-	$10 \cdot \log \left(\frac{P_{in}}{P_{cou} + P_{out}}\right)$	
Return Loss	S11 S22 S33 S44	$10 \cdot \log \left( \frac{P_{in}}{P_{back}} \right)$	
Amplitude Balance	-	$10 \cdot \log \left( \frac{P_{cou}}{\frac{P_{cou} + P_{out}}{2}} \right)$	
Phase Balance         S41           S31		Phase <sub>(S41)</sub> - Phase <sub>(S31)</sub>	

Table 2. Mathematical Formula for the CMX25S03 Parameters

NOTE

- P<sub>in</sub>: Power of Input Port
- Pout: Power of Output Port

• P<sub>cou</sub> : Power of Coupling Port

- Piso: Power of Isolated Port
- P<sub>back</sub>: Return Power of Input Port



#### 10.2 RN2 Technologies TEST BOARD LAYOUT

*Figure 6* shows the RN2 Technologies test board layout used for testing the CMX25S03 RF performance. The RN2 Technologies test board is based on the Taconic RF35 board with the dielectric constant of 3.5, board thickness of 0.8 mm, and copper of 1 Oz.

We recommend that you use the same material and design layout, as shown in *Figure 6*, to meet the specifications in this datasheet. However, if you use different materials, you must follow the basic guidelines. See <u>'*RECOMMENDED PCB LAYOUT AND SOLDER MASK PATTERN'*</u> for more details.




Figure 6. RN2 Technologies Test Board Layout



#### **10.3 AUTOMATIC PORT EXTENSIONS (APE) FUNCTION**

To accurately measure the CMX25S03 s-parameters, we use the Automatic Port Extensions (APE) function of the VNA. The APE function is used for reducing or eliminating both electrical delay and insertion loss of test fixtures. It provides a convenient, automated way to calculate the insertion loss and electrical delay terms by a simple measurement of an open or short circuit, which is easy to do in test fixtures.

We consider the transmission lines of the RN2 Technologies bare test board as extensions of the coaxial test cables that are between the Vector network analyzer and the CMX25S03. With the APE function, we extend the coaxial test ports so that our calibration plane is right at the terminals of the CMX25S03, and not at the connectors of the RN2 Technologies bare test board.




Figure 7. Performing the APE Function Test



#### **11. RECOMMENDED PCB LAND PATTERN**

*Figure 8* shows the recommended PCB layout and solder mask pattern to meet the specifications in this datasheet. When you use different materials other than the RN2 Technologies test board, you must follow the basic guidelines and calculate the 50 ohm impedance line width using a different PCB stack information.

#### **Basic Guidelines**

- Place GND more than 30% of the CMX25S03 GND dimension regardless of a via size.
- Appropriately increase via sizes and numbers to allow low impedance ground connection and good thermal conductivity.
- Align the CMX25S03 ground plane with the solder to have good connection to ground.
- Fill the via holes under the CMX25S03 with the solder for thermal emission.

# **NOTE**: Contact the RN2 Technologies sales team for more detailed PCB layout and solder mask pattern information.




Figure 8. Recommended PCB Layout and Solder Mask Pattern



## **12. SOLDERING PROCESS**

The CMX25S03 soldering steps are as follows:

- 1. Cleaning the PCB
- 2. Applying solder paste to the PCB
- 3. Placing the CMX25S03 on the PCB
- 4. Reflowing the CMX25S03 to the PCB
- 5. Cleaning and inspecting the soldered PCB with the CMX25S03

#### STEP 1: Cleaning the PCB

Carefully clean the PCB surface where the CMX25S03 is soldered.

Particles must not be placed on the PCB surface where the CMX25S03 is soldered.




Figure 9. Cleaning the PCB Surface Where the CMX25S03 is Soldered

#### STEP 2: Applying the Solder Paste to the PCB

Apply the solder paste to the 11 points on the PCB surface.

It enables good thermal conductivity because the CMX25S03 is firmly attached to the PCB surface without air.




Figure 10. Applying the Solder Paste to the 11 Points on the PCB Surface



#### STEP 3: Placing the CMX25S03 on the PCB

Correctly place the CMX25S03 on the 11 points of the PCB surface.

Applying the solder paste to the 11 points helps you firmly attach the CMX25S03 to the PCB surface.




Figure 11. Placing the CMX25S03 on the 11 Points of the PCB Surface

#### STEP 4: Reflowing the CMX25S03 to the PCB

We recommend both manual soldering and PCB surface pre-heating methods when reflowing the CMX25S03 to the PCB surface. Be careful NOT to touch the iron tip to the CMX25S03 when you use the manual soldering method.

See <u>'REFLOW PROFILE'</u> for more details.

#### **13. REFLOW PROFILE**

*Figure 11* shows the thermal reflow profile of the SAC-305 (Alpha metal), which is a test solder cream we used.





Figure 12. Thermal Reflow Profile

	Ramp Up	Pre-Heating	Peak	Soaking
Temperature(℃)	T1:160±5	T2:180±5	T4:260±5	T3:230±5
Time(sec)	t1:60±5	t2:100±15	t3:30±5	t4:60±10



## **14. PACKAGING AND ORDERING INFORMATION**





#### **15. HANDLING GUIDE**

PLEASE READ THIS NOTICE BEFORE USING OUR LTCC DOHERTY COMBINERS.

#### I. Be careful when transporting

- Ensure proper transportation as excessive stress or shock may damage LTCC Doherty combiner due to the nature of ceramics structure.
- LTCC Doherty combiner cracked or damaged on terminals may have their property changed.

#### II. Be careful during storage

- Store LTCC Doherty combiners in the temperature of -55 °C to +125 °C.
- Keep the humidity at 45 % to 75 % around LTCC Doherty combiners.
- Prevent corrosive gas (Cl<sub>2</sub>, NH<sub>3</sub>, SO<sub>X</sub>, NO<sub>X</sub>, etc.) from contacting LTCC Doherty combiners.
- It is recommended to use LTCC Doherty combiners within 6 months of receipt. If the period exceeds 6 months, solderability may need to be verified.

#### III. Be careful when soldering

- Solder all the ground terminals, IN and OUT pad of LTCC Doherty combiners on the ground plane of the PCB.
- LTCC Doherty combiners may be cracked or broken by uneven forces from a claw or suction device.
- Mechanical stress by any other devices may damage LTCC Doherty combiners when positioning them on PCB.
- Do not use dropped LTCC Doherty combiners.
- Ensure that any soldering is carried out by the condition of specification sheet.
- Do not re-use LTCC Doherty combiners which are de-soldered from PCB.



## **16. LEGAL INFORMATION**

Information in this document is believed to be accurate and reliable. However, RN2 Technologies does not give any representations or warranties, expressed or implied, as to the accuracy or completeness of such information and shall have no liability for the consequences of use of such information. RN2 Technologies does not take any responsibility for the content in this document if provided by an information source outside of RN2 Technologies.

RN2 Technologies reserves the right to make changes to information published in this document, including without limitation specifications and product descriptions, at any time and without notice. This document supersedes and replaces all information supplied prior to the publication hereof.

RN2 Technologies products are not authorized for use in safety-critical applications (such as life support) where a failure of the RN2 Technologies products would reasonably be expected to cause severe personal injury or death, unless officers of the parties have executed an agreement specifically governing such use. Buyers represent that they have all necessary expertise in the safety and regulatory ramifications of their applications, and acknowledge and agree that they are solely responsible for all legal, regulatory and safety-related requirements concerning their products and any use of RN2 Technologies products in such safety-critical applications, notwithstanding any applications-related information or support that may be provided by RN2 Technologies. Further, Buyers must fully indemnify RN2 Technologies and its representatives against any damages arising out of the use of RN2 Technologies products in such safety-critical applications.

RN2 Technologies does not accept any liability related to any default, damage, costs or problem which is based on any weakness or default in the customer's applications or products. Customer is responsible for doing all necessary testing for the customer's applications or products using RN2 Technologies products in order to avoid a default of the applications and the products. RN2 Technologies does not accept any liability in this respect.

**RN2** Technologies

#### HTTP://WWW.RN2.CO.KR

RI.2 Technologies